

Ovation


Instruction Manual



Blender

OV9185

PARTS



A. Assembled Jar

B. Main Body

C. Speed Control Knob

D. Inner Lid

E. Jar Lid

F. Jar

G. Ring / Seal

H. Blades

I. Jar Base

IMPORTANT SAFETY REMINDERS

When using electrical appliance, basic safety precaution should always be followed including the following:

1. Read all instructions before using.
2. To protect against risk of electrical shock, do not put the unit in water or other liquids.
3. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
4. Avoid contact with moving parts.
5. To reduce the risk of electric shock, do not modify the plug in any way.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. Return appliance to the nearest authorized service center.
7. Do not use outdoors.
8. Do not let cord hang over edge of a table or counter.
9. Keep hands and utensils out of container while blending to reduce the risk of injury or damage to the blender. A scraper may be used *only* when the blender is not running.
10. Blades are sharp. Handle with extreme care.
11. To reduce the risk of injury, never place cutter-assembly blades on base without the jug being properly attached.
12. Be certain cover is securely locked in place before operating appliance.
13. Always operate blender with cover in place.
14. Only use the appliance for its intended purpose.
15. The use of attachments or accessories, which are not included with the product, is not recommended as it may cause a hazard or injuries.
16. This product is intended for domestic / household use only.
17. Note that the maximum operating time for the blender is 3 minutes.

Extra note to the following:

1. This appliance is not intended for long time operation.
2. This appliance must not operate when there's nothing in the jar.

3. WARNING: DO NOT USE THE BLENDER FOR HOT LIQUIDS / FOOD.

4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
5. The appliance should be repaired by qualified professionals.
6. Always disconnect and switch off the appliance when not in use or before assembling, disassembling or cleaning. Extra care should be taken when handling the blades during cleaning.

SAVE THESE INSTRUCTIONS

Before first use

- All parts of the blender are to be thoroughly cleaned before using for the first time.
- Take out the required length of cable from the cable tidy on the base of the blender and connect the device to the mains supply.

USING YOUR APPLIANCE

Assembly of the glass jar



1. Put the rubber ring on the inner edge of the blades.
2. Put the blades with ring into the jar base.
3. Mount the glass jar onto the jar base and turn clockwise until it's fixed.
4. To insert the glass jar onto the main body, make sure that the blender is switched off (Switch in the '0' setting). Place the jar on the base and press down until securely engaged.
5. After putting your ingredients in the jar, fix the lid onto the jar by pressing down.
6. Insert the inner lid into the opening of the jar lid and turn counter-clockwise until it's locked.
7. Switch on to desired setting.

Settings for your blender

| Speed setting | Use |
|---------------|--|
| 1 | for light usage with liquids |
| 2 | for more solid consistency - for mixing liquids and solid food |
| M | for ice crushing and short, powerful impulse movements |

* The switch does not permanently engage in the 'M' setting. You have to hold the switch to the 'M' setting or turn it repeatedly to the 'M' setting.

Reminders:

- After using the blender, always return the switch to the '0' setting and pull out the mains plug.
- To remove the glass jar, just lift it up. You do not have to rotate the glass jar to remove it.

Useful tips

- To achieve the best results when pureeing solid ingredients, place small portions into the glass jar one by one instead of placing a large quantity all at once.
- If you are processing solid ingredients, cut them into small pieces (2-3cm) first.
- When mixing solid ingredients, start off first with a small amount of liquid. Gradually add more and more liquid through the opening in the lid.
- Always place your hand on top of the blender when you are using the device.
- Be careful when processing hot liquids.
- For stirring solid or very thick liquid ingredients, we recommend that you use the blender in impulse mode to prevent the blades from becoming stuck.

CLEANING

- Never immerse the main body in water. Simply wipe away dirt with a moist cloth.
- To clean the glass jar, empty it and fill it with water. Place it on the main body and turn the switch on several times to the 'M' setting.
- Empty the glass jar and rinse until clean.
- Ensure that the glass jar is completely empty before you unscrew the ring.
- Be careful when handling the blades.
- All removable parts are suitable for the dishwasher.